



FIG.1 CRANKCASE. / GEAR ASSY, GOVERNOR. (E01)




REF.NO.	PART NO.	DESCRIPTION	Q'TY
E01-1	11310-Z531310-0099	CRANKCASE SUBASSEMBLY.	1
E01-2	37060-Z010120-0000	SENSOR, ENGINE OIL	1
E01-3	16400-Z0X0110-00A0	GEAR ASSY, GOVERNOR	1
E01-4	16061-Z010110-00A0	ARM, GOVERNOR	1
E01-5	11007-Z010110-00A0	BOLT, DRAIN PLUG	2
E01-6	90408-Z010510-00A0	FLAT WASHER - GRADE A	2
E01-7	90547-0205-CLAT	DEEP GROOVE BALL BEARING	1
E01-8	90682-Z300110-00A0	SEAL, OIL	1
E01-9	90305-Z010210-01A0	HEXAGON NUT WITH FLANGE	1
E01-10	90408-Z010210-00A0	FLAT WASHER	1
E01-11	90501-Z010110-0000	COTTER PIN	1
E01-12	90001-0614-01A0	HEXAGON SOCKET FLANGE FACE BOLT - SMALL SERIES	2

FIG.2 COVER SUBASSEMBLY, CRANKCASE (E02)




REF.NO.	PART NO.	DESCRIPTION	Q'TY
E02-1	11411-Z530111-00A0	COVER, CRANKCASE	1
E02-2	90547-0205-CLAT	DEEP GROOVE BALL BEARING	1
E02-3	90682-Z300110-00A0	SEAL, OIL	1
E02-4	11001-Z440110-00A0	GASKET, CRANKCASE	1
E02-5	90502-0810-00A0	POSITION PIN	2
E02-6	15010-Z010130-Q500	DIPSTICK SUBASSEMBLY, OIL	1
E02-7	90001-0832-01A0	BOLT	6

FIG.3 HEAD SUBASSEMBLY, CYLINDER / PLUG,SPARK (E03)




REF.NO.	PART NO.	DESCRIPTION	Q'TY
E03-1	12140-Z950210-00A0	HEAD SUBASSEMBLY, CYLINDER	1
E03-2	12131-Z950110-00A0	GASKET, CYLINDER HEAD	1
E03-3	12410-Z950210-00A0	COVER SUBASSEMBLY, CYLINDER HEAD	1
E03-4	12004-Z950410-00A0	CYLINDER HEAD COVER GASKET	1
E03-5	17004-Z010310-00A0	TUBE, BREATHER	1
E03-6	90001-0612-01A0	BOLT	4
E03-7	90204-Z010210-0000	STUD BOLT	2
E03-8	90203-Z010110-0000	STUD BOLT	2
E03-9	90502-1114-00A0	POSITION PIN	2
E03-10	12003-Z010110-00A0	CYLINDER HEAD BOLT	4
E03-11	30010-Z010110-00A0	PLUG, SPARK	1
E03-12	12419-Z950311-00A0	CYLINDER HEAD COVER PIN LIMIT PLATE	1
E03-13	90001-0610-01A0	BOLT	1
E03-14	37009-Z430110-0000	SENSOR, TEMPERATURE	1

FIG.4 ROD,CRANKSHAFT CONNETING (E04)




REF.NO.	PART NO.	DESCRIPTION	Q'TY
E04-1	13300-Z950111-00A1	CRANKSHAFT ASSY.	1


FIG.5 RING SET,OIL / ROD,CRANKSHAFT CONNETING (E05)




REF.NO.	PART NO.	DESCRIPTION	Q'TY
E05-1	13200-Z140210-00A9	RING ASSY, PISTON	1
E05-2	13122-Z010110-00A0	CLIP, PISTON PIN	2
E05-3	13111-Z950120-00A0	PISTON	1
E05-4	13121-Z010110-00A0	PIN, PISTON	1
E05-5	13010-Z950110-00A0	ROD, CONNECTING	1

FIG.6 TRAIN,VALVE / CAMSHAFT SUBASSEMBLY (E06)



REF.NO.	PART NO.	DESCRIPTION	Q'TY
E06-1	14200-Z950120-00A0	CAMSHAFT ASSY.	1
E06-2	12110-Z950110-00A0	VALVES SET	1
E06-3	12101-Z810210-00A0	GUIDE, SEAL	1
E06-4	12103-Z010110-00A0	SPRING, VALVE	2
E06-5	12112-Z810210-00A0	SEAT, VALVE SPRING	2
E06-6	12109-Z810110-00A0	CLAMP, VALVE LOCK	4
E06-7	14081-Z040110-00A0	TAPPET, VALVE	2
E06-8	14071-Z950110-00A0	LIFTER, VALVE	2
E06-9	14310-Z950110-00A0	ROCKER SUBASSEMBLY, VALVE	2
E06-12	14318-Z950110-00A0	SHAFT SUBASSEMBLY, ROCKER	2

FIG.7 STARTER,RECOIL (E07)


REF.NO.	PART NO.	DESCRIPTION	Q'TY
E07-1	90001-0608-01A0	BOLT	4
E07-2	28200-Z260210-H701	STARTER ASSY, RECOIL	1

FIG.8 SHROUD / SHIELD,LOWER (E08)


REF.NO.	PART NO.	DESCRIPTION	Q'TY
E08-1	28110-Z200420-GJA0	SHROUD	1
E08-2	19304-Z950120-0000	SHROUD, CYLINDER BODY	1
E08-3	19340-Z050120-0000	SHIELD,LOWER	1
E08-4	37050-Z010210-0000	PROTECTOR, OIL	1
E08-5	90001-0612-01A0	BOLT	4
E08-6	90001-0610-01A0	BOLT	3


FIG.9 CARBURETOR ASSY. (E09)


REF.NO.	PART NO.	DESCRIPTION	Q'TY
E09-1	16100-Z952410-00A0	CARBURETOR ASSY.	1
E09-2	17001-Z010110-00A0	AIR CLEANER SEAL GASKET	1
E09-3	16001-Z010110-00A0	CARBURETOR SEAL GASKET	1
E09-4	16003-Z950110-00A0	PLATE, CARBURETOR INSULATOR	1
E09-5	16002-Z950110-0000	GASKET, CARBURETOR INSULATOR	1

123 G3800-RELT PARTS LIST


01/06/2022

FIG.10 FLYWHEEL / IMPELLER / STARTER PULLEY / IGNITION COIL (E10)




REF.NO.	PART NO.	DESCRIPTION	Q'TY
E10-1	13501-Z010110-00A0	NUT, FLYWHEEL	1
E10-2	28002-Z010310-0000	PULLEY,STARTER	1
E10-3	19352-Z010310-00A0	IMPELLER	1
E10-4	13510-Z200210-00A0	FLYWHEEL SUBASSEMBLY	1
E10-5	30400-Z440410-00B0	COIL, IGNITION	1
E10-6	90001-0625-01A0	BOLT	2
E10-10	30001-Z200110-0000	CLAMP, CHARGE COIL	1
E10-11	90001-0610-01A0	BOLT	1
E10-12	30140-Z160230-0000	COIL SUBASSEMBLY, CHARGE	1
E10-13	90001-0628-01A0	BOLT	2


FIG.11 CONTROL ASSY, THROTTLE (E11)



REF.NO.	PART NO.	DESCRIPTION	Q'TY
E11-1	16520-Z040130-0000	CONTROL ASSY, THROTTLE	1
E11-2	16063-Z950210-00A0	SPRING, GOVERNOR	1
E11-3	16062-Z010210-00A0	ROD, GOVERNEOR	1
E11-4	16012-Z010310-00A0	SPRING, THROTTLE VALVE RETURNING	1
E11-5	16070-Z010110-00A0	GOVERNOR BRACKET SUBASSEMBLY	1
E11-6	90001-0610-01A0	BOLT	2
E11-7	16072-Z010110-00A0	BOLT, GOVERNOR SUPPORT	1
E11-8	90305-0600-31A0	HEXAGON NUT WITH FLANGE	1


FIG.12: STARTER MOTOR (E12)


REF.NO.	PART NO.	DESCRIPTION	Q'TY
E12-1	09100-Z200310-0000	STARTING MOTOR ASSEMBLY	1
E12-2	90001-0635-01A0	BOLT	1
E12-3	90502-0912-00A0	POSITION PIN	2
E12-4	90684-Z030120-0000	WIRE CLIP	1
E12-5	90001-0625-01A0	BOLT	1

FIG.13 CLEANER, AIR (F01)



REF.NO.	PART NO.	DESCRIPTION	Q'TY
F01-1	90305-0600-31A0	HEXAGON NUT WITH FLANGE	2
F01-2	17100-Z0X0110-0000	AIR CLEANER	1
F01-3	90722-Z010610-0000	PLUG, END	1

FIG.14 MUFFLER ASSY. (F02)




REF.NO.	PART NO.	DESCRIPTION	Q'TY
F02-1	18100-YJW0110-WFA0	MUFFLER ASSY.	1
F02-2	90303-0800-31A0	HEXAGON NUT	2
F02-3	18001-Z950110-00A0	GASKET, EXHAUST OUTLET	2
F02-4	18030-YF20110-H3A0	BRACKET,MUFFLER	1
F02-5	90001-0816-03	BOLT	1
F02-6	90001-0612-03	BOLT	2

FIG.15 TANK ASSY, FUEL (F03)




REF.NO.	PART NO.	DESCRIPTION	Q'TY
F03-1	90007-0625-A3	BOLT	4
F03-2	90408-Y020110-0000	FLAT WASHER	4
F03-3	90683-Y020110-0000	BUSH	4
F03-4	16601-Y020120-0000	#N/A	4
F03-5	90104-0512-53	BOLT	2
F03-6	37200-Y1J0110-H7A0	LEVELER ASSY, OIL	1
F03-7	16730-Y020130-H7A0	COVER, FUEL TANK	1
F03-8	16652-Y020120-00A0	STRAINER, FUEL	1
F03-9	16620-YF20210-GJA0	FUEL TANK	1
F03-10	16750-Y020211-0000	COCK ASSY, FUEL	1
F03-11	30431-YBW0210-0000	JACKET, RUBBER	1
F03-12	90740-Z010210-00A0	COLLAR	1
F03-13	90686-Z2Z0110-00A0	TUBE, FUEL	1
F03-14	90740-Z010510-00A0	COLLAR	1

FIG.16 FRAME, ENGINE (F04)




REF.NO.	PART NO.	DESCRIPTION	Q'TY
F04-1	51100-YF20310-H7A0	FRAME ASSY, ENGINE	1
F04-2	90305-0800-31A0	HEXAGON NUT WITH FLANGE	8
F04-3	51005HY020410-0000	CUSHION, ENGINE FRAME	2
F04-4	51011HY020410-0000	CUSHION, ENGINE FRAME RIGHT	2
F04-5	51016-Y9X0110-H7A0	SUPPORT, ENGINE FRAME SHOCK ABSORPTION	1
F04-6	90001-0816-03	BOLT	2
F04-7	51014HY940110-0000	SEAT, ENGINE FRAME SHOCK ABSORPTION	2
F04-8	90001-0620-03	BOLT	2
F04-9	31110-Y030710-00A0	BATTERY	1
F04-10	31142-YA60110-H7A0	CLAMP, BATTERY	1
F04-11	90007-0616-A3	BOLT	2
F04-12	31112HY120110-0000	WIRE, ANODE	1
F04-13	31114HY130410-0000	WIRE, CATHODE	1
F04-14	90305-0800-33	HEXAGON NUT WITH FLANGE	1
F04-15	90305-0600-33	HEXAGON NUT WITH FLANGE	2

FIG.17 PANEL SUBASSEMBLY, CONTROL (F05)




REF.NO.	PART NO.	DESCRIPTION	Q'TY
F05-1	35610-YF20810-H700	PANEL SUBASSEMBLY, CONTROL	1
F05-2	90326-Y2V0110-00A0		4
F05-3	90007-0640-A3	BOLT	4
F05-4	35220-Y3Y0110-0000	STARTING SWITCH	1
F05-5	35632-YMA0110-0000	TIMER	1
F05-6	30008-YF30110-0000	CONTROL MODULE	1
F05-7	35648-Y9H0110-0000	AIR SWITCH	1
F05-8	35614-Y560110-0000	SOCKET SUBASSEMBLY, POWER SUPPLY	1
F05-10	35160-YDT0110-0000	SWITCH SUBASSEMBLY	1
F05-11	35629-YF80110-0000	TERMINAL SUBASSEMBLY, GROUNDING	1

FIG.18 ROTOR/STATOR (F06)



REF.NO.	PART NO.	DESCRIPTION	Q'TY
F06-1	31300-YF20310-0000	MOTOR ASSY.	1
F06-2	30022-Y020110-GJ00	MOTOR TAIL COVER	1
F06-3	90001-0512-01A0	BOLT	4
F06-4	30021-Y020310-00A0	MOTOR SUPPORT	1
F06-5	90408-Y020210-00A0	FLAT WASHER	1
F06-6	30048-YE30110-0000	STATOR BOLT	4
F06-7	30049-YE30110-0000	BOLT, ROTOR	1
F06-8	30060-YF20110-0000	REGULATOR, VOLTAGE	1
F06-9	90001-0512-01A0	BOLT	2
F06-10	90001-0512-03	BOLT	2
F06-11	90007-0612-A1A0	BOLT	1
F06-12	30023-Y020110-0000	STOPPER, MOTOR RIGHT COVER	1

FIG.19 WHEEL ASSY,FRONT /FRAME, ENGINE (F07)



REF.NO.	PART NO.	DESCRIPTION	Q'TY
F07-1	44020-YF20110-0100	SHAFT, FRONT WHEEL	2
F07-2	44110-Y9X0110-GZ00	WHEEL, FRONT	2
F07-3	90501-Y2C0110-01A0	COTTER PIN	2
F07-4	90001-0875-03	BOLT	2
F07-5	90504-Y910110-0000	PIN SHAFT	1
F07-6	54110-YF20110-H700	HANDLE TUBE ASSY	1
F07-7	90310-0800-33	NUT	2
F07-8	54101-Y9P0110-0000	SLEEVE, HANDLE RUBBER	1
F07-9	90793-Y910110-00A0	Sling	1