

HD80CL(E) Parts List					P/N:HLDP80CLA202502-A
No	Part No	Description		Qty.	Note
1	HL80C-02202	Joint grip	锁紧螺母	2	
2	HL80C-02203	Pipe joint	水管接头	2	
3	HL80C-02204	Gasket,Rubber	水管接头垫片	2	
4	5789-10025c2	Bolt M10×25	异形螺栓M10×25	12	
5	HL80C-02201	Suction flange	进水接头	1	
6	HL80C-02205	Check valve	拍门	1	
7	HL80C-02108	Housing of pump	泵体	1	
8	HL80C-02302	Rubber pad	出水接头垫片	1	
9	HL80C-02301	Discharge flange	出水接头	1	
10	HL80C-02101	O-Ring	螺塞密封圈	2	
11	HL80C-02102	Plug	螺塞	2	
12	3452.1-2200400	O-Ring Ø220×4	O型密封圈Ø220×4	1	
13	HL80C-02103	Washer,Rubber	导流器密封圈73×7	1	
14	5783-08020a2	Bolt M8×20	螺栓M8×20	2	Electric
15	HL80C-02104	Volute casing	导流器	1	
16	HL80C-02105	Water pump impeller	叶轮	1	
17	HL80C-02120	Machinery seal	机械密封	1	
18	HL80C-02107	Pump cover	泵盖	1	
19	HL80C-02412	Filter net	滤网	1	
20	HL50CE-01210	Battery rack	电瓶板	1	Electric
21	5789-06014a2	Bolt M6×14	异形螺M6×14	1	Electric
22	HL50CE-04003	Battery spacer	电瓶垫片	1	Electric
23	HL80C-02420	Clamp	滤网接头卡箍	3	
24	HL50C-02106	Aluminum washer Ø8	铝垫Ø8	4	
25	5783-08030c2	Bolt M8×30	螺栓M8×30	4	
26	HL2500CLE-01212a	Battery hanger bolt	电瓶钩	2	Electric
27	93-05c	Washer Ø5	弹垫Ø5	2	Electric
28	93-08a	Washer Ø8	弹垫Ø8	2	
29	97.1-05c	Flat washer Ø5	平垫Ø5	2	Electric
30	HL50CE-04030	Lamp holder	低油压指示灯灯座	1	Electric
31	97.1-08a	Flat washer Ø8	平垫Ø8	2	
32	5783-05010C2	Bolt M5×10	螺栓M5×10	2	Electric
33	HL2500CLE-01211	Battery platen	电瓶压条	1	Electric
34	HL178FAP2(E)	Diesel Engine	柴油机	1	
35	HD80CLE-01100	Frame	机架	1	
36	97.1-10a	Flat washer Ø10	平垫Ø10	10	
37	93-10a	Washer Ø10	弹垫Ø10	10	
38	6170-10000a2	Nut M10	螺母M10	10	
39	HD80CE-01310a	Bracket	水泵托盘	1	
40	5783-10045a2	Bolt M10×45	螺栓M10×45	4	
41	HL4000CL-05100	Absorber 3KW	3KW减震垫	4	
42	5783-10025a2	Bolt M10×25	螺栓M10×25	2	

43	818-05012a2	Screw M5×12	螺钉M5×12	2	
44	97.1-05a	Flat washer Ø5	平垫Ø5	2	
45	HL2500CL-04020	Fuel meter assy.	浮标	1	
46	HL2500CL-04003	Fuel meter gasket	浮标垫片	1	
47	HL2500CL-04030	Fuel tank gap assy.	油箱盖	1	
48	HL2500CL-04004	Fuel tank gap gasket	油箱盖密封圈	1	
49	HL170F-10020	Filter cup	油杯	1	
50	5783-06022a2	Bolt M6×22	螺栓M6×22	4	
51	96.1-06a	Flat washer Ø6	大边平垫Ø6	4	
52	HL170F-01202	Bush	衬套	4	
53	HL170F-01201	Shock absorber bushing	减震套	4	
54	HL170F-10013	Clamp Ø9	回油管卡箍 Ø9	2	
55	HL170F-10012	Fuel oil return pipe	回油管	1	
56	HL2500CL-04010A	Fuel tank assy.	油箱	1	
57	97.1-06a	Flat washer Ø6	平垫Ø6	6(9)	(Electric)
58	93-06a	Washer Ø6	弹垫Ø6	4(7)	(Electric)
59	6170-06000a2	Nut M6	螺母 M6	6(7)	(Electric)
60	HL178F-10300	Filter element assy.	柴油滤总成	1	
61	HL2500CL-04002	Fuel oil filter gasket	柴油滤连接板垫片	1	
62	HL2500CL-04001	Shim plate	柴油滤连接板	1	
63	818-05008a2	Screw M5×8	螺钉 M5×8	3	
64	HL170F-10405	Fuel tank cock gasket	油开关垫片	1	
65	HL170F-10400A	Fuel tank cock assy.	油开关	1	
66	HL170F-10009	Fuel oil pipe	输油管	1	
67	HL170F-10011	Clamp Ø13	输油管卡箍 Ø13	2	
68	62-06000a2	Fly nut M6	蝶形螺母M 6	2	Electric
69	HL2500CLE-05202	Battery wire(red)	电瓶线(红色)	1	Electric
70-1	HL50CE-04010	Starter switch and connection assy.	起动开关及线束总成	1	Electric
70-2	HL50CE-04020	Starter switch and connection assy.	起动开关及线束总成(含低油压指示灯)	1	Electric
71	HL2500CLE-05203	Battery wire (black)	电瓶线(黑色)	1	Electric
72	HL2500CLE-05205	Jacket of battery(red)	电瓶护套 (红色)	1	Electric
73	HL2500CLE-05204a	Battery	电瓶	1	Electric