




Part No.	Description	Q'ty	Part No.	Description	Q'ty
1	Circlips	3	31	Knife	2
2	Wheel	2	32	Bolt M8x25	8
3	Flange nut M8	34	33	Side cover	1
4	Belt cover	1	34	Bearing cover	1
5	Bolt M8x16	9	35	Bearing cover plate	1
6	Key parallel pin	1	36	"Box cover (Only apply on electric start engine)"	1
7	Pulley	1	37	"Battery (Only apply on electric start engine)"	1
8	Belt	2	38	"Battery box (Only apply on electric start engine)"	1
9	Flange nut M10	14	39	Support stand	1
10	Bearing Seat	2	40	Stand pad	2
11	Bearing	2	41	Flange Bolt M8x30	4
12	Clutch	1	42	Socket head cap screw M8x50	1
13	Clutch support	1	43	Guard plate	2
14	Switch box	2	44	Guard plate	1
15	Fixed block	2	45	Hopper guard	1
16	Fixed block	2	46	Socket head cap screw M6x40	4
17	Microswitch	4	47	Flange nut M6	13
18	Sheet	2	48	Flange Bolt M6x20	7
19	Retaining plate	2	49	Handle	1
20	Emergency stop button	1	50	In-feed bin	1
21	Switch seat	1	51	Inserting piece	1
22	Flange Bolt M10x30	6	52	Flange Bolt M8x20	2
23	Base frame	1	53	Inserting piece	1
24	Hex head bolts	1	54	Discharge chute	1
25	Engine pulley	1	55	Handwheel	1
26	Connection plate	1	56	Flange Bolt M6x16	2
27	Engine	1	57	Splash guard	1
28	Engine flat key	1			
29	Bolt M10x40	4			
30	Chipper drum	1			