


COM E5020S (HM0.75*2JW/50L) SPARE PARTS LIST - Pump Model:



NO	Item	Req Qty	BAR Part #	BAR Kit Part Number	Kit Description
1	cover	4	COS E5020S-1		
2	Left fan	2	COS E5020S-2		
3	crankshaft	4	COS E5020S-3		
4	hexagon socket screw	4	COS E5020S-4		
5	connecting rod	4	COS E5020S-5		
6	piston cup	4	COS E5020S-6		
7	pressing plate	4	COS E5020S-7		
8	cross recess head screw	4	COS E5020S-8		
9	cylinder	4	COS E5020S-9		
10	left box body	2	COS E5020S-10		
11	Seal Gasket for Cylinder	4	COS E5020S-11	COS E5020S-74	Cylinder Head Service Kit
12	valve plate	4	COS E5020S-12		
13	Cylinder head gasket	4	COS E5020S-13		
14	cylinder head	4	COS E5020S-14		
15	hexagon socket screw	24	COS E5020S-15		
16	Connection aluminum tube	4	COS E5020S-16	COS E5020S-75	Connection Tube Kit
17	tube o-rings	8	COS E5020S-17		
18	cross recess pan head screw	4	COS E5020S-18		
19	stop block	4	COS E5020S-19	COS E5020S-76	Cylinder Head Service Kit 2
20	Out of the air valve slice	4	COS E5020S-20		
21	Intake valve slice	4	COS E5020S-21		
22	Gasket Tensioner	4	COS E5020S-22		
23	Socket head screw	4	COS E5020S-23		
24	Right fan	2	COS E5020S-24		
25	bearing	4	COS E5020S-25		
26	The right Box	2	COS E5020S-26		
27	Lead skirts	2	COS E5020S-27		
28	hexagon bolt	16	COS E5020S-28		
29	Cross pan head screw	16	COS E5020S-29		
30	stator	2	COS E5020S-30		
31	Hexagon nuts	4	COS E5020S-31		

32	rotor	2	COS E5020S-32		
33	Pump Mount	8	COS E5020S-33		
34	hexagon nut	8	COS E5020S-34		
35	elbow	2	COS E5020S-35		
36	Plastic Cover	1	COS E5020S-36		
37	tank	1	COS E5020S-37		
38	wired hose	2	COS E5020S-38		
39	Non Return Valve	2	COS E5020S-39	COS E5020S-77	Non Return Valve Kit
40	solenoid valve	2	COS E5020S-40		
41	hex nut	2	COS E5020S-41		
42	Rubber	2	COS E5020S-42		
43	flat gasket	2	COS E5020S-43		
44	hexagon bolt	2	COS E5020S-44		
45	drain valve	1	COS E5020S-45		
46	axle	2	COS E5020S-46		
47	idler wheel	2	COS E5020S-47		
48	spring washer	2	COS E5020S-48		
49	hex nut	2	COS E5020S-49		
50	Unloading nut	1	COS E5020S-50	COS E5020S-78	Unloader Pipe Kit
51	Unloading pipe	1	COS E5020S-51		
52	paper pad	2	COS E5020S-52		
53	switch connector	1	COS E5020S-53		
54	switch union nut	1	COS E5020S-54		
55	safety valve	1	COS E5020S-55		
56	pressure switch	1	COS E5020S-56	COS E5020S-79	Pressure Switch/Regulator Kit
57	double joint	1	COS E5020S-57		
58	Oil-water filter	1	COS E5020S-58		
59	deflation valve	2	COS E5020S-59		
60	pressure gage Y40	1	COS E5020S-60		
61	pressure gage Y50	1	COS E5020S-61		
62	Electrical wires	1	COS E5020S-62		
63	amphenol connector O type	1	COS E5020S-63		
64	amphenol connector U type	2	COS E5020S-64		
65	Power plug	1	COS E5020S-65		
66	Seal nuts	2	COS E5020S-66		
67	capacitance	2	COS E5020S-67		
68	air filter	2	COS E5020S-68		
69	Pump head cover	2	COS E5020S-69		
70	ST4.8*40	4	COS E5020S-70		
71	capacitance box	1	COS E5020S-71		
72	capacitance box screw	4	COS E5020S-72		
73	Complete Pump Suit E5020S	2	COS E5020S-73		